

0 °F to 500 °F, Temperature – Entropy Diagram for AIR

